


MIXING FAUCET

1)



2) same as #1 with blade handles



- handles: forged brass four-arm handles with color-coded index discs

mixing faucet (with VB)

- 1) L414-8VB-55-BO140S
2) L424-8VB

3)



4)



mixing faucet (no VB)

- 3) L414-8BH
4) L2224-BH



*serrated tip available
-BO140S

standard mixing faucet

mixing faucet: deck-mounted, with hot and cold water

valve units: self-contained compression valve with replaceable stainless steel seats

gooseneck: 8" rigid/swing convertible gooseneck

inlet: 1-3/16" male shank with (2) 3/8" OD flexible copper tubes; furnished complete with locknut and washer

outlet: 3/8" NPS female outlet; included ten serration hose end or aerator

vacuum breaker (VB): integral vacuum breaker to prevent backflow; breaker has replaceable seat and ultra-light float cup to resist spilling at low flow (#1 & #2 only)

finish: forged brass with polished chrome plated finish

handles (BH): 4" forged brass wrist blade handles with color-coded index discs

PURE WATER FAUCET



pure water faucet

L7833SC

standard pure water faucet

pure water faucet: deck mounted; for distilled, de-ionized or reverse osmosis water

interior lining: inert polypropylene; pure water comes in contact only with inert plastic

valve units: diaphragm-type valve; brass valve stem and bonnet with inert elastomer diaphragm; valve has manual on/off switch

handles: black nylon knurled handle with color-coded index discs

riser: 6" rigid brass riser

inlet: 3/8" IPS male shank with 3/8" OD tube connection, furnished complete with 3/8" OD compression adaptor for inlet

outlet: seven serration plastic hose end

finish: forged brass with polished chrome plated finish

SINGLE MOTION EYEWASH & DRENCH HOSE



pull down

EW849LH-L
EW849LH

- swinging head down to operational position activates water flow
- remains in operation until spray head is returned to storage position



drench hose

EW1022

eyewash and drench hose

spray head assembly: two GS-Plus™ spray heads with "flip top" dust covers and internal flow control

valve: 1/2" IPS plug-type valve with Teflon® coated O-ring seals

strainer: in-line strainer to protect valve and spray head from debris

supply: 1/2" NPT male inlet

sign: ANSI-compliant identification sign

finish: forged brass with polished chrome plated finish

ELECTRIC PEDESTAL BOX



outlet fitting

- E300WS - single gang, single face
- E400WS - single gang, double face
- E500WS - double gang, single face
- E600WS - double gang, double face

- UL-listed
- complete with grounding screws, mounting shank and locknut
- wrinkle black powder coated finish
- *electrical outlets and plate not included

standard valves

valve unit: quarter-turn open/close with chrome plated brass ball and molded TFE seals

handle: chrome plated forged brass lever handle with color-coded index disc

inlet: furnished with 3/8" IPS mounting shank (assembled), locknut and washer, NPT male inlet

outlet: 3/8" NPT female outlet with removable ten serration hose end

finish: forged brass with polished chrome plated finish

BALL VALVES

services available:

	AIR - ORANGE
	NIT - BROWN
	VAC - YELLOW



wall mount

L4200-158WSA



deck mount single

L4200-131WSA



deck mount single

L4200-132WSA

	GAS - BLUE
--	------------

wall mount

L4160CV-158WSA

FUME HOOD PLUMBING

services available:

	AIR - ORANGE
	GAS - BLUE
	NIT - BROWN
	VAC - YELLOW
	CW - GREEN



outlet fitting

L022-WSA
L022CV-WSA

- use with fume hood gas valves
- mounting: panel mounted flange with 45 degree angle hose end; furnished with mounting shank, locknut and washer; 3/8" NPT male inlet
- natural gas supplied with internal check valve (CV)
- brass outlet fittings with a powder coated finish to match service index button color



rod-driven valve

(gasses) L3185N - "L" dimension 9.5"
(water) L3185W - "L" dimension 30"

- angle pattern valve for installation within side wall of hood; inlet and outlet are 90°; 3/8" NPT female inlet and outlet
- valve type: needle valve for gasses and water valves as required
- valve body: forged brass
- fully assembled and factory tested prior to shipment
- can be plumbed up or down in field



panel-mounted gooseneck

L074-WSA

- use with fume hood water valves
- backflow prevention: includes (L108) in-line vacuum breaker
- mounting: panel mounted turret with 6" rigid/swing gooseneck; furnished with mounting shank, locknut and washer; 3/8" NPT male inlet