



We put space to work.

Item # _____

Job _____

SUPER ERECTA SHELF® SOLID SHELVING (18-Gauge)

- **Strength:** Two-fold thickness of 18-gauge steel forms 1/8" (3.2mm) raised edges on all four sides of the shelving. This ship's edge gives all-around rigidity and high strength.
- **Weight Load Capacity:** 48" (1219mm) and shorter holds 800lbs (363kg) per shelf, 60" (1524mm) holds 600lbs (272kg) per shelf, 72" (1829mm) holds 300lbs (136kg) per shelf.
- **Sanitary:** Flat, solid style with the raised ship's edge on all four sides and at the corners contains spills, minimizes contamination and permits easier clean-up. Louvered/embossed shelf design allows air circulation under packages and containers.
- **Galvanized Shelves** with uncoated cast corners are ideal for applications requiring solid shelving or a work surface and minimum resistance to corrosion. Available in flat solid and louvered/embossed styles.
- **Standard Type 304 Stainless Steel** shelves with epoxy-coated cast corners address the majority of applications for solid, corrosion resistant shelves or work surfaces. Available in flat solid and louvered/embossed styles.
- **Premium Autoclave/Cart Washable Type 304 Stainless Steel** solid shelves feature an all-stainless construction to withstand high temperature, corrosive applications. Available in flat solid style.
- **Versatile Construction:** Super Erecta Shelf® solid shelving can change as quickly as your needs change. By using various accessories hundreds of shelving configurations become possible.
- **Shelf Accessibility:** Shelves can be loaded/unloaded from all sides. This open construction allows use of the maximum storage space of the cube.
- **Adjustability:** Shelves can be adjusted in 1" (25mm) intervals along the entire length of the post.
- **Adjustable Feet:** Leveling bolts compensate for surface irregularities. Note: Stainless steel stationary posts include stainless leveling bolts.



Raised Ship's Edge



All Metro Catalog Sheets are available on our website: www.metro.com



888.635.2080 | newenglandlab.com

L02-014 Printed in U.S.A. 10/18

Information and specifications are subject to change without notice. Please confirm at time of order.

Copyright © 2018 InterMetro Industries Corp.



SUPER ERECTA SHELF®
Solid Shelving (18-Gauge)

10.20



SUPER ERECTA SHELF® SOLID SHELVING (18-Gauge)

We put space to work.®

Galvanized shelves have uncoated, cast aluminum corners. Standard Type 304 Stainless Steel shelves have black epoxy-coated corners. Autoclavable/cart washable Type 304 Stainless Steel shelves have stainless corners.

Nominal Width/Length (in.) (mm)	Approx. Pkd. Wt. (lbs.) (kg)	GALVANIZED		STAINLESS STEEL		Autoclavable Cart Washable Stainless Steel Flat Stainless
		Flat Galvanized	Louvered/ Embossed Galvanized	Flat Stainless	Louvered/ Embossed Stainless	
14x24 355x610	10 4.5	1424FG	1424LG	1424FS	1424LS	1424NFS
14x30 355x760	12 5.4	1430FG	1430LG	1430FS	1430LS	1430NFS
14x36 355x914	14 6.4	1436FG	1436LG	1436FS	1436LS	1436NFS
14x42 355x1066	15 6.8	1442FG	1442LG	1442FS	1442LS	1442NFS
14x48 355x1219	17 7.7	1448FG	1448LG	1448FS	1448LS	1448NFS
14x60 355x1524	22 9.9	1460FG	1460LG	1460FS	1460LS	1460NFS
18x24 457x610	11 5.0	1824FG	1824LG	1824FS	1824LS	1824NFS
18x30 457x760	14 6.4	1830FG	1830LG	1830FS	1830LS	1830NFS
18x36 457x914	16 7.3	1836FG	1836LG	1836FS	1836LS	1836NFS
18x42 457x1066	18 8.2	1842FG	1842LG	1842FS	1842LS	1842NFS
18x48 457x1219	20 9.1	1848FG	1848LG	1848FS	1848LS	1848NFS
18x60 457x1524	24 10.9	1860FG	1860LG	1860FS	1860LS	1860NFS
18x72 457x1829	29 13.2	1872FG	—	1872FS	—	*
21x24 530x610	13 5.9	2124FG	2124LG	2124FS	2124LS	2124NFS
21x30 530x760	15 6.8	2130FG	2130LG	2130FS	2130LS	2130NFS
21x36 530x914	18 8.2	2136FG	2136LG	2136FS	2136LS	2136NFS
21x42 530x1066	21 9.5	2142FG	2142LG	2142FS	2142LS	2142NFS
21x48 530x1219	23 10.4	2148FG	2148LG	2148FS	2148LS	2148NFS
21x60 530x1524	26 11.8	2160FG	2160LG	2160FS	2160LS	2160NFS
24x24 610x610	15 6.8	2424FG	2424LG	2424FS	2424LS	2424NFS
24x30 610x760	17 7.7	2430FG	2430LG	2430FS	2430LS	2430NFS
24x36 610x914	19 8.6	2436FG	2436LG	2436FS	2436LS	2436NFS
24x42 610x1066	21 9.5	2442FG	2442LG	2442FS	2442LS	2442NFS
24x48 610x1219	24 10.9	2448FG	2448LG	2448FS	2448LS	2448NFS
24x60 610x1524	29 14.0	2460FG	2460LG	2460FS	2460LS	2460NFS
24x72 610x1829	33 15.0	2472FG	—	2472FS	—	*

*Contact your Metro representative for availability.



SiteSelect Posts for Super Erecta® Solid Shelving

Stationary posts are fitted with adjustable leveling bolts to compensate for uneven surfaces. Mobile posts will accept stem casters (see Cat. Sheet 11.20). Height for stationary units includes leveling bolt and cap.

Actual Height* (in.) (mm)	STATIONARY*		MOBILE		Approx. Pkd. Wt. (lbs.) (kg)	
	Model No. Plated	Model No. Stainless	Model No. Plated	Model No. Stainless		
7 ³ / ₈ 187	7P	—	6 ³ / ₄ 171	7UP	—	1/2 0.3
14 ³ / ₈ 365	13P	13PS	13 ³ / ₄ 349	13UP	13UPS	1 0.5
28 ³ / ₈ 720	27P	27PS	27 ³ / ₄ 704	27UP	27UPS	1 ³ / ₄ 0.75
34 ³ / ₈ 873	33P	33PS	33 ³ / ₄ 857	33UP	33UPS	2 0.9
54 ⁷ / ₁₆ 1382	54P	54PS	53 ¹³ / ₁₆ 1366	54UP	54UPS	3 1.4
62 ⁷ / ₁₆ 1585	63P	63PS	61 ¹³ / ₁₆ 1570	63UP	63UPS	3 ¹ / ₂ 1.6
—	—	—	69 ³ / ₄ 1771	70UP	—	3 ³ / ₄ 1.7
74 ¹ / ₂ 1892	74P	74PS	73 ⁷ / ₈ 1876	74UP	74UPS	4 1.8
86 ¹ / ₂ 2197	86P	86PS	85 ⁷ / ₈ 2181	86UP	86UPS	4 ¹ / ₂ 2.0
96 ¹ / ₂ 2450	96P	—	—	—	—	5 ¹ / ₂ 2.5

*Actual height for the stationary post includes the post cap and the leveling bolt completely tightened.

SiteSelect Posts for Autoclavable/ Cart-Washable Applications



Designed for use with stem casters and fitted with swaged aluminum post caps.

9986S

Actual Height (in.) (mm)	Approx. Pkd. Wt. (lbs.) (kg)	Model No. Stainless Steel
33 ³ / ₄ 857	2 0.9	33UPS-SW
53 ¹³ / ₁₆ 1366	3 1.4	54UPS-SW
61 ¹³ / ₁₆ 1570	3 ¹ / ₂ 1.6	63UPS-SW

Order aluminum split sleeves with stainless "C" rings or corrosive, high-temperature autoclave or cart washing applications.
Model No. **9986S**
One bag required per shelf.

